Wheel Alignment Maintenance Instructions

Proper wheel alignment is crucial for ensuring a smooth ride, better fuel efficiency, and longer tyre life. Here's a complete guide to maintaining wheel alignment:

1. Why Wheel Alignment Matters:

- Ensures even tyre wear.
- Improves vehicle handling and stability.
- Increases fuel efficiency.
- Prolongs tyre life.
- Prevents strain on suspension components.

2. Signs Your Wheels Need Alignment:

- Uneven or rapid tyre wear.
- Vehicle pulling to one side while driving.
- Steering wheel is off-center when driving straight.
- Vibrating or noisy steering wheel.
- Decreased fuel efficiency.

3. Recommended Maintenance Schedule:

- Check alignment every 6,000 to 10,000 km or as recommended by the vehicle manufacturer.
- Get an alignment after installing new tyres.
- Check alignment after any significant impact (e.g., hitting a pothole or curb).
- Regularly inspect alignment during routine maintenance.

4. DIY Wheel Alignment Check:

- Step 1: Park the car on a flat, level surface.
- Step 2: Inspect tyre wear patterns. Uneven wear indicates misalignment.
- Step 3: Check the steering wheel position while driving straight.
- Step 4: Measure the toe angle using a measuring tape between the front and back edges of the front tyres.
- Step 5: Compare measurements and check the manufacturer's specifications.

5. Professional Wheel Alignment Procedure:

- The technician will inspect and adjust the following angles:
 - Camber: Tilt of the tyre inward or outward.
 - Toe: The angle the tyres turn inward or outward.
 - Caster: Steering pivot angle (affects stability).

•	A computerized alignment machine is used to adjust these
	angles to factory specifications.

6. Maintenance Tips:

- Rotate tyres regularly to ensure even wear.
- Keep tyres properly inflated.
- Inspect suspension and steering components periodically.
- Avoid overloading your vehicle.

7. Benefits of Proper Alignment:

- Smooth and comfortable driving experience.
- Reduced tyre wear and replacement costs.
- Enhanced safety and vehicle control.
- Better fuel efficiency.

8. Cost of Wheel Alignment:

The average cost of a wheel alignment ranges from ₹1,000 to
₹2,500, depending on the vehicle type and service center.

9. DIY vs. Professional Alignment:

- DIY Alignment: Suitable for minor adjustments or quick checks.
- Professional Alignment: Recommended for accurate, long-lasting results.